

山梨県民文化ホール(小ホール)

調光器負荷名称表

NO.1調光器盤	
DMX	負荷名称
1	PL1
2	PL2
3	PL3
4	PL4
5	PL5
6	PL6
7	PL7
8	PL8
9	PL9
10	PL10
11	PL11
12	PL12
13	1B上1
14	1B上2
15	1B上3
16	1B上4
17	1B中1
18	1B中2
19	1B中3
20	1B中4
21	1B下1
22	1B下2
23	1B下3
24	1B下4
25	2B上1
26	2B上2
27	2B上3
28	2B上4
29	2B中1
30	2B中2

NO.2調光器盤	
DMX	負荷名称
31	2B中3
32	2B中4
33	2B下1
34	2B下2
35	2B下3
36	2B下4
37	3B上1
38	3B上2
39	3B上3
40	3B上4
41	3B中1
42	3B中2
43	3B中3
44	3B中4
45	3B下1
46	3B下2
47	3B下3
48	3B下4
49	4B上1
50	4B上2
51	4B上3
52	4B上4
53	4B中1
54	4B中2
55	4B中3
56	4B中4
57	4B下1
58	4B下2
59	4B下3
60	4B下4

NO.3調光器盤	
DMX	負荷名称
61	TL上1
62	TL上2
63	TL上3
64	TL上4
65	TL下1
66	TL下2
67	TL下3
68	TL下4
69	1TW1
70	1TW2
71	1TW3
72	1TW4
73	1TW下1
74	1TW下2
75	1TW下3
76	1TW下4
77	2TW上1
78	2TW上2
79	2TW上3
80	2TW上4
81	2TW下1
82	2TW下2
83	2TW下3
84	2TW下4
85	3TW上1
86	3TW上2
87	3TW上3
88	3TW上4
89	3TW下1
90	3TW下2

NO.4調光器盤	
DMX	負荷名称
91	3TW下3
92	3TW下4
93	FS上1
94	FS上2
95	FS上3
96	FS上4
97	FS上5
98	FS上6
99	FS上7
100	FS上8
101	FS上9
102	FS上10
103	FS上11
104	FS下1
105	FS下2
106	FS下3
107	FS下4
108	FS下5
109	FS下6
110	FS下7
111	FS下8
112	FS下9
113	FS下10
114	FS下11
115	1CL1
116	1CL2
117	1CL3
118	1CL4
119	1CL5
120	1CL6

NO.5調光器盤	
DMX	負荷名称
121	1CL7
122	1CL8
123	1CL9
124	1CL10
125	1CL11
126	1CL12
127	1CL13
128	1CL14
129	1CL15
130	1CL16
131	F1
132	F2
133	F3
134	F4
135	F前C1
136	F前C2
137	F前C3
138	F前C4
139	花F上1
140	花F上2
141	花F下1
142	花F下2
143	FC上1
144	FC上2
145	FC上3
146	FC上4
147	FC上5
148	FC上6
149	FC上7
150	FC上8

NO.6調光器盤	
DMX	負荷名称
151	FC上9
152	FC上10
153	FC上11
154	FC上12
155	FC下1
156	FC下2
157	FC下3
158	FC下4
159	FC下5
160	FC下6
161	FC下7
162	FC下8
163	FC下9
164	FC下10
165	FC下11
166	FC下12
167	OFC1
168	OFC2
169	OFC3
170	OFC4
171	FC奥1
172	FC奥2
173	FC上61
174	FC上62
175	FC上63
176	FC上64
177	FC下61
178	FC下62
179	FC下63
180	FC下64

NO.7調光器盤	
DMX	負荷名称
181	1S1
182	1S2
183	1S3
184	1S4
185	1S5
186	1S6
187	1S7
188	1S8
189	1S9
190	1S10
191	1S11
192	1S12
193	1S13
194	1S14
195	1S15
196	1S16
197	2S1
198	2S2
199	2S3
200	2S4
201	2S5
202	2S6
203	2S7
204	2S8
205	2S9
206	2S10
207	2S11
208	2S12
209	2S13
210	2S14

反響1
反響2
反響3
反響4

NO.8調光器盤	
DMX	負荷名称
211	2S15
212	2S16
213	3S1
214	3S2
215	3S3
216	3S4
217	3S5
218	3S6
219	3S7
220	3S8
221	3S9
222	3S10
223	3S11
224	3S12
225	3S13
226	3S14
227	3S15
228	3S16
229	4S1
230	4S2
231	4S3
232	4S4
233	4S5
234	4S6
235	4S7
236	4S8
237	4S9
238	4S10
239	4S11
240	4S12

NO.9調光器盤	
DMX	負荷名称
241	5S1
242	5S2
243	5S3
244	5S4
245	5S5
246	5S6
247	5S7
248	5S8
249	5S9
250	5S10
251	5S11
252	5S12
253	UH上1
254	UH上2
255	UH上3
256	UH上4
257	UH上5
258	UH上6
259	UH下1
260	UH下2
261	UH下3
262	UH下4
263	UH下5
264	UH下6
265	2CL1
266	2CL2
267	2CL3
268	2CL4
269	2CL5
270	2CL6

NO.10調光器盤	
DMX	負荷名称
271	2CL7
272	2CL8
273	2CL9
274	2CL10
275	2CL11
276	2CL12
277	LH1
278	LH2
279	LH3
280	LH4
281	LH5
282	LH6
283	LH7
284	LH8
285	LH9
286	LH10
287	LH11
288	LH12
289	FSC上1
290	FSC上2
291	FSC下1
292	FSC下2
293	天井1
294	天井2
295	ブラケット

72
78
59
22
40
W
72
78
59
22
40
W